

## Alcatel Mobile Phones

Model	Direct Dialing	Dialing from International SIM Menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
OT535	ok	ok	ok		ok	

## Apple

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
iPhone	OK	OK	OK	Settings/Phone/SIM Applications	OK	When dialed directly, will provide false message answer.
iPhone 3G	OK	OK	OK	Settings/Phone/SIM Applications	OK	<a href="#">Program 1101 for full compatibility.</a>
iPhone 3GS	OK	OK	OK	Settings/Phone/SIM Applications	OK	<a href="#">Program 1101 for full compatibility.</a>
iPhone 4	OK	OK	OK	Settings/Phone/SIM Applications	OK	Must purchase the <a href="#">Micro SIM</a> version of our global SIM card. <a href="#">Program 1101 for full compatibility.</a> May receive "call failed" error before the ring back, please ignore this message.
iPad 3G, iPad 2	n/a	n/a	n/a	Settings/Phone/SIM Applications	OK	Must purchase the <a href="#">Micro SIM</a> version of our global SIM card

## BlackBerry - RIM

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data*	Notes
BlackBerry 7100	No	OK if available	OK	Not available on some software versions	No	Not recommended
BlackBerry 7290	No	OK if available	OK	Not available on some software versions	No	Not recommended
BlackBerry 8520	OK	OK	OK	Main Menu	Yes	BlackBerry servers are not supported
BlackBerry 8700, 8700c	OK	OK	OK	Main Menu	Yes	BlackBerry servers are not supported
BlackBerry 8800, 8820	OK	OK	OK	Main Menu	Yes	BlackBerry servers are not supported
BlackBerry Bold 9000	OK	OK	OK	Main Menu	Yes	BlackBerry servers are not supported
BlackBerry Bold 9700	OK	OK	OK	Main Menu	Yes	BlackBerry servers are not supported
BlackBerry Curve 8200, 8220	OK	OK	OK	Main Menu	Yes	BlackBerry servers are not supported
BlackBerry Curve 8300, 8310, 8320	OK	OK	OK	Main Menu	Yes	BlackBerry servers are not supported
BlackBerry Curve	OK	OK	OK	Main Menu	Yes	BlackBerry servers are not supported

8900						
BlackBerry Pearl 8100, 8110	OK	OK	OK	Main Menu	Yes	BlackBerry servers are not supported
BlackBerry Tour 9630 (Verizon)	OK	OK	OK	Main Menu	Yes	BlackBerry servers are not supported
BlackBerry World Edition, including most Sprint and Verizon BlackBerry phones (Storm, etc)	No	No	No	No	Varies	Most Verizon and Sprint World Edition BlackBerrys (8830/Bold/etc.) require special dialing instructions to make outgoing calls. You can receive calls normally, but to call out you will need to send a free SMS to initiate the call. <a href="#">See calling instructions here.</a>

\* GPRS Data Service is available on BlackBerry models from 8000 and up.

## Google Android

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
Google Android V1.5	no	no	ok	There is no International SIM Menu	ok	Dialing out requires prefix *146* #. Number could be entered with *146* in the address book with the # at the end of the number. Example: *146*0016174895952#  All 09X functions should be dialed as: *146*09X# Example: To check balance: *146*099# To Recharge: *146*098XXXX*YY#
Google Android Nexus	no	no	ok	There is no International SIM Menu	ok	Dialing out requires prefix *146* #. Number could be entered with *146* in the address book with the # at the end of the number. Example: *146*0016174895952#  All 09X functions should be dialed as: *146*09X# Example: To check balance: *146*099# To Recharge: *146*098XXXX*YY#
Google Android V2.2 and higher	OK	OK	OK	Download International SIM Direct Android App from Android Market. The app removes the callback and allows direct dial from the phone book.	ok	International SIM Menu is labeled as SIM Toolkit

## HTC Mobile Phones

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
HTC TYLT	NO	OK	OK	Main Menu	ok	
HTC Diamond	OK	OK	OK	Main Menu	ok	
HTC Touch	OK	OK	OK	Main Menu	ok	

HTC Snap - S522	OK	OK	OK	Main Menu	ok	<a href="#">Program 1101 for full compatibility.</a>
Sprint HTC Touch 7138	OK	OK	OK	Main Menu	ok	<a href="#">Program 1101 for full compatibility.</a>
HTC G1 (T-Mobile G1)	no	no	ok	There is no International SIM Menu	ok	Dialing out requires prefix *146* #. Number could be entered with *146* in the address book with the # at the end of the number. Example: *146*0016174895952#  All 09X functions should be dialed as: *146*09X# Example: To check balance: *146*099# To Recharge:*146*098XXXX*YY#
HTC Bravo, Desire, Desire S, HD, A8181 -Android	no	no	ok	There is no International SIM Menu. Download International SIM Direct Android App from Android Market. The app removes the callback and allows direct dial from the phone book.	ok	Download International SIM Direct app from Android Market for easy dialing and the removal of ringback. Without the app, dialing out requires prefix *146* #. Number could be entered with *146* in the address book with the # at the end of the number. Example: *146*0016174895952#  All 09X functions should be dialed as: *146*09X# Example: To check balance: *146*099# To Recharge:*146*098XXXX*YY#
HTC Legend	no	no	ok	There is no International SIM Menu	ok	Dialing out requires prefix *146* #. Number could be entered with *146* in the address book with the # at the end of the number. Example: *146*0016174895952#  All 09X functions should be dialed as: *146*09X# Example: To check balance: *146*099# To Recharge:*146*098XXXX*YY#
HTC Nexus One	no	no	ok	There is no International SIM Menu	ok	Dialing out requires prefix *146* #. Number could be entered with *146* in the address book with the # at the end of the number. Example: *146*0016174895952#  All 09X functions should be dialed as: *146*09X# Example: To check balance: *146*099# To Recharge:*146*098XXXX*YY#
Verizon HTC Ozone	No	No	No	No	Varies	You can receive calls normally, but to call out you will need to send a free SMS to initiate the call. <a href="#">See calling instructions here.</a>

## LG Phones

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
LG CF360	NO	NO	NO	My Stuff	ok	LG CF360 phone requires special dialing instructions to make outgoing calls. You can receive calls normally, but to call out you will need to send a free SMS to initiate the call. <a href="#">See calling instructions here.</a>
LG CG300	NO	NO	OK	No Menu	OK	<a href="#">Program 1101 for full compatibility</a>
LG CU400	OK	OK	OK	My Stuff	ok	<a href="#">Program 1101 for full compatibility</a>
LG CU405	OK	OK	OK	My Stuff	ok	<a href="#">Program 1101 for full compatibility</a>
LG CU500	OK	OK	OK	My Stuff	ok	Change Settings in Settings - Network menu of the phone to 2G, rather than 3G. <a href="#">Program 1101 for full compatibility</a>
LG CU515	NO	NO	NO	My Stuff	ok	LG CU 515 phone requires special dialing instructions to make outgoing calls. You can receive calls normally, but to call out you will need to send a free SMS to initiate the call. <a href="#">See calling instructions here.</a>
LG CU720	OK	OK	OK	My Stuff	ok	<a href="#">Program 1101 is required for full compatibility</a>
LG-GR500, Xenon	NO	NO	NO	No Menu	No	LG GR phone series require special dialing instructions to make outgoing calls. You can receive calls normally, but to call out you will need to send a free SMS to initiate the call. <a href="#">See calling instructions here.</a>
LG GW525	NO	NO	NO	My Stuff	OK	LG KP phone series require special dialing instructions to make outgoing calls. You can receive calls normally, but to call out you will need to send a free SMS to initiate the call. <a href="#">See calling instructions here</a>
LG GX200	OK	OK	OK	Tools->SIM services	OK	<a href="#">Program 1101 could be required for full compatibility</a>
LG-KC910	NO	NO	NO	Extra	No	LG KC phone series require special dialing instructions to make outgoing calls. You can receive calls normally, but to call out you will need to send a free SMS to initiate the call. <a href="#">See calling instructions here.</a>
LG-KP202	NO	NO	NO	Extra	No	LG KP phone series require special dialing instructions to make outgoing calls. You can receive calls normally, but to call out you will need to send a free SMS to initiate the call. <a href="#">See calling instructions here.</a>
LG-KP500 - "Cookie"	NO	NO	NO	Extra	No	LG KP phone series require special dialing instructions to make outgoing calls. You can receive calls normally, but to call out you will need to send a free SMS to initiate the call. <a href="#">See calling instructions here.</a>

## Motorola Phones

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
Motorola Phones					ok	Most Motorola phones work with International SIM.

Motorola A1200	OK	OK	OK	Applications	ok	
Motorola KRZR K1	OK	OK	OK	Applications	ok	Some versions of T- Mobile phones do not have International SIM Menu.
Motorola PP7389i	NO	NO	NO	Applications	NO	This old model seems to be not compatible with International SIM.
Motorola RAZR V3, V3i	OK	OK	OK	Applications	ok	Some versions of T- Mobile phones do not have International SIM Menu.
Motorola RIZR Z3	OK	OK	OK	Applications	ok	Some versions of T- Mobile phones do not have International SIM Menu.
Motorola SLVR L6, L7	OK	OK	OK	Applications	ok	
Motorola V180	OK	OK	OK	Applications	ok	
Motorola V190, V195	OK	OK	OK	Applications	ok	
Motorola V220	OK	OK	OK	Applications	ok	
Motorola V551	OK	OK	OK	Applications	ok	
Motorola V600	OK	OK	OK	Applications	ok	
Motorola V975	OK	OK	OK	Applications	ok	
Motorola V980	OK	OK	OK	Applications	ok	
Motorola W490	OK	OK	OK	Applications	ok	
Motorola W510	OK	OK	OK	Applications	ok	
Motorola Droid 2 Global (Verizon)	OK	OK	OK	App Drawer	ok	Phone does not work in the USA on GSM bands.

## NEC Mobile Phones

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
NEC 525	NO	NO	OK	Main Menu	ok	

## Nokia Cell Phones

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
1100	ok	ok	ok		ok	
1101	ok	ok	ok		ok	
1202	ok	ok	ok		ok	
1209	ok	ok	ok		ok	
1600	ok	ok	ok	in Main menu	ok	
1650	ok	ok	ok	in Main menu	ok	
2100	not working	no menu	ok	not working	ok	
2610	not working	no menu	ok	not working	ok	

2730	not working	no menu	ok	not working	ok	
3120	not working	ok	not working	in Main menu	ok	
3230	ok	ok	ok		ok	
3250	ok	ok	ok		ok	099 does not work in direct dialing
3310	not working	not working	ok	in Main menu	ok	
3410	not working	not working	ok	in Main menu	ok	
3510	not working	ok	ok	in Main menu	ok	
5140	ok	ok	ok		ok	099 does not work in direct dialing
5300	ok	ok	ok		ok	099 does not work in direct dialing
6021	ok	ok	ok	in Main menu	ok	099 does not work in direct dialing
6085	ok	ok	ok	in Main menu	ok	099 does not work in direct dialing
6100	ok	ok	ok	in Main menu	ok	099 does not work in direct dialing
6101	ok	ok	ok	in Main menu	ok	099 does not work in direct dialing
6103	ok	ok	ok	in Main menu	ok	099 does not work in direct dialing
6111	ok	ok	ok		ok	099 does not work in direct dialing
6120	ok	ok	ok		ok	099 does not work in direct dialing
6121	ok	ok	ok		ok	099 does not work in direct dialing
6126	ok	ok	ok		ok	099 does not work in direct dialing
6131	ok	ok	ok		ok	099 does not work in direct dialing
6220	ok	ok	ok		ok	099 does not work in direct dialing
6230	ok	ok	ok		ok	099 does not work in direct dialing
6270	ok	ok	ok		ok	099 does not work in direct dialing
6300	no	ok	ok	in Main menu	ok	
6310, 6310i	no	ok	ok	in Main menu	ok	
6610	ok	ok	ok		ok	
6610i	ok	ok	ok		ok	
7210	ok	ok	ok	in Main menu	ok	
7280	ok	ok	ok		ok	
7370	ok	ok	ok		ok	099 does not work in direct dialing
8800	ok	ok	ok		ok	099 does not work in direct dialing
C2-01	ok	ok	ok	in Main Menu	ok	Does not display any messages on the screen after pressing send. Please wait a few seconds for phone to ring back to connect.
C6	ok	ok	ok	Applications. You need to switch the phone to on-line mode to see the menu.	ok	Ignore Message: Call is not allowed
E51	ok	ok	ok		ok	Ignore Message: Call is not allowed
E60-1	ok	ok	ok		ok	Ignore Message: Call is not allowed
E61	ok	ok	ok		ok	Ignore Message: Call is not allowed
E62	ok	ok	ok		ok	Ignore Message: Call is not allowed
E63	ok	ok	ok		ok	Ignore Message: Call is not allowed
E71	ok	ok	ok		ok	Ignore Message: Call is not allowed
E72	ok	ok	ok		ok	Ignore Message: Call is not allowed
E90	ok	ok	ok		ok	Ignore Message: Call is not allowed
N70	ok	ok	ok		ok	Ignore Message: Call is not allowed
N73	ok	ok	ok		ok	Ignore Message: Call is not allowed

N 90, 90-1	ok	ok	ok		ok	Ignore Message: Call is not allowed
N93	ok	ok	ok		ok	Ignore Message: Call is not allowed
N95	ok	ok	ok		ok	Ignore Message: Call is not allowed
N96	ok	ok	ok		ok	Ignore Message: Call is not allowed
N97	ok	ok	ok		ok	Ignore Message: Call is not allowed
N900	no	no	ok	not available	ok	Must use messaging method. Some versions may support *146* dialing.

## Palm Treo

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
Palm Treo Pro	ok	ok	ok	Programs	ok	Windows Mobile Palm PRO is fully compatible.
Palm Treo 650	ok	ok	ok	Tools-Utilities-SIM Services Menu	ok	<a href="#">Program 1101 is required for full compatibility.</a> Ignore "Number not allowed" message after programming 1101
Palm Treo 680	ok	ok	ok	Utility Menu	ok	<a href="#">Program 1101 is required for full compatibility</a>
Palm Treo 750	ok	ok	ok	Programs	ok	Windows Mobile Palm PRO is fully compatible.

## Sagem

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
VS-1	ok	ok	ok		ok	
VS-4	ok	ok	ok		ok	

## Samsung Mobile Phones

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
SGH-100	not working	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-600	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-A177	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-A237	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>

SGH-A437	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-A707	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-A737	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-A867	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-C417/416	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-B2100 Explorer	no	no	no	Main-Tools	ok	Samsung B2100 phone requires special dialing instructions to make outgoing calls. You can receive calls normally, but to call out you will need to send a free SMS to initiate the call. <a href="#">See calling instructions here.</a>
SGH-C417/416	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-D500	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-D520	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-D600	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-D800	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-D880	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-E330N	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-E350E	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-E530	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-i607 (BlackJack)	ok	ok	ok	Main-Tools	ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-i617 (BlackJack 2)	ok	ok	ok		ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-M310						Phone does not recognise International SIM
SGH-T399	no	ok	ok		ok	Calls can be made by dialing *146* prefix or from the International SIM menu only.
SGH-T429	ok	ok	ok		ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-U600	ok	ok	ok		ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-X620	ok	ok	ok		ok	<a href="#">Program 1101 is required for full compatibility</a>
Renown SCH-U800	no	no	ok	No International SIM Menu	ok	Calls can be made only with *146* prefix on this Verizon CDMA/GSM phone.
SGH-X621	ok	ok	ok		ok	<a href="#">Program 1101 is required for full compatibility</a>
SGH-X700	ok	ok	ok		ok	<a href="#">Program 1101 is required for full compatibility</a>
I 5500, Corby, Galaxy 5	ok	ok	ok		ok	Use International SIM Direct App for easy calling and removal of the CallBack.
Galaxy S	ok	ok	ok		ok	Use International SIM Direct App for easy calling and removal of the CallBack.
SGH-Z540	ok	ok	ok		ok	<a href="#">Program 1101 is required for full compatibility</a>

## Sharp

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
903	ok	ok	ok		ok	
GX-15	ok	ok	ok		ok	
GX-17	ok	ok	ok		ok	

## Siemens Mobile Phones

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
A70	ok	ok	ok	in Extras	ok	
A75	ok	ok	ok	in Extras	ok	
CX65	ok	ok	ok	in Extras	ok	
C75	ok	ok	ok	in Extras	ok	
SL55	ok	ok	ok	in Extras	ok	

## Sony Ericsson Phones

Model	Direct Dialing	Dialing from International SIM menu	Dialing via Prefix *146*	Location of International SIM menu	GPRS Data	Notes
Cedar	ok	ok	ok	Entertainment	ok	